

FU XIANG CABINETS WAREHOUSE

KITCHEN • BATH • ORGANIZATION

ASSEMBLY INSTRUCTIONS Kitchen & Bathroom Sink Cabinets

(This assembly instruction sheet applies for all our Sink Base Cabinets.)

❖ General Instruction

- Read the instruction carefully before starting the installation.
- Follow all generally accepted safety procedures during assembly.
- Parts List: The following items are included in the carton.

ITEM	DESCRIPTION	Qty
Α	Face Frame w/ Door	1
В	Side Panel (Right & Left)	2
С	Bottom Panel	1
D	Toe Kick	1
E	Back Panel	1

NOTE: FACE FRAME & DOOR for BCF and BCR are in separate carton

***** Instruction

- STEP 1: Put the Face Frame (A) down on a soft flat working surface and insert two (B) side panels into the grooves of Face Frame (A). Align the metal clip lock connector and lock it with a screwdriver.
- STEP 2: Spread the Side Panels (B) gently and insert Bottom Panel (C) into the grooves of Face Frame (A) and Side Panels (B) until it touches the Face Frame (A). Confirm that all is flush and lock connectors as STEP 1.
- STEP 3: Install the Toe Kick (D) on the Side Panels (B) at the front of the cabinet. Confirm that all is flush and lock as STEP1. Stand the cabinet upright and attached the 4 plastic Corner Braces in each corner of the cabinet by using screws. Then install back panel (E) attach to side panels (B).
- STEP 4: Sink Base Cabinet is now complete. To install the sink base cabinet, confirm the condition of the wall (e.g., drywall, concrete, tiles) for proper method of the cabinet installation. Example: To install the sink cabinet on the drywall, run a stud finder along the drywall.

